

200/300 Series


CompX cabinet eLock Instructions



Thank you for purchasing the CompX eLock. The information contained in these instructions is intended to serve as a guide so as to allow the eLock to be quickly and easily put into service. CompX's 300 Series eLock can be configured to work in conjunction with existing 802.11g or Ethernet networks.

For complete set up and installation instructions for networked and stand-alone eLocks, please see the "Help" section in CompX's LockView v4 software.

Network **cabinet** eLock has three components:




eLock controller

1. Dot matrix LCD
2. Network button (blue LED)
3. "UP" button
4. "NEXT/SELECT" button
5. "BACK/CANCEL" button
6. "MENU" button
7. "DOWN" button
8. + Button
9. - Button
10. Low battery indicator (yellow LED)
11. Magstripe reader location (if equipped)
12. HID Prox or HID iCLASS reader location (if equipped)
13. "ENTER" button
14. "CLEAR" button
15. Alpha-numeric keypad





200/300 Series Cabinet eLock – Components




Installation example

Cabinet door installation shown. eLock can also be installed on drawers.



Back view: eLock controller

Battery cable connector



200/300 Series Cabinet eLock Components
continued on page 5

**TEMPLATE ON
OPPOSITE PAGE**

