

Preparing Signal for Use:

1) Insert AC/DC plug into Warning Light's respective jack. Plug AC/DC adapter into wall outlet.

2) Uncoil cord with Door Ajar Alert attached.

3) Fasten Door Ajar Alert to the edges of your door/

window. Place signal light where it is sure to be seen.

4) Make sure to Test (see below). Unit is now set for Door Ajar Alert service.

The Door Ajar Warning Light System is a complete signal system. The light will automatically start flashing when the complimentary sensors separate. AC Power Supply ensures the light will flash with no need to change batteries. So stop crossing your fingers, hoping your door/window is secure.

Testing the Door Ajar Alert Signal Check operating condition periodically (suggested bi-annually). Always assure yourself that the system is functioning properly before you rely on it. After pluging in the AC power adapter, with the Door Ajar Alert sensors separated, the light will start to flash immediately. When the Door Ajar Alert sensors contact eachother, the light will stop flashing.

Door Ajar Warning Light Turns ON when contacts have separated

Door Ajar Alert easily mounts to most surfaces

We strongly recommend labeling the outlet where this system is installed to not unplug.

Here's why the unique Door Ajar Warning Signal System has been preferred for 40 years:

- A complete signal system. Nothing more to add.
- AC powered to give its warning signal without need to replace batteries.
- Clear powerful flashers alert friends, neighbors or caretaker to possible danger.
- Simple to understand, test and use.
- The choice of real estate professionals; ski, vacation and weekend home owners; farmers; fuel dealers and more ...
- Reliable, low-cost protection against the worry of thawed cold goods or energy consumption.

Limited Warranty:

Warrantor: Dealer, Distributor, Retailer, and Manufacturer Warranties and Remedy We believe that this is a high quality product. Although we test all products for proper functionality, we cannot guaranty that there will never be a defective unit. For this reason, it must be clear that the Warrantors are not insuring your product/premises or guaranteeing that there will not be damage to your person or property if you use this Product. If this warranty is unacceptable please return the unused product for a full refund.

One Year Limited Warranty - TIPTEMP warrants this product to be free from defects in material and workmanship under normal use for one year, and is not responsible for consequential damage or installation costs of any nature. In event that the Product does not conform to this Warranty at any time during the period of one year from original purchase date, Warrantor will repair the defect and return it to you at no charge. Important: The Warranty is limited to replacement of the Product ONLY.

This warranty shall terminate and be of no further effect at the time the Product is 1) damaged by extraneous causes such as fire, water, etc. or not maintained as reasonable and necessary: 2) modified: 3) improperly installed: 4) repaired by someone other than the Warrantor: 5) used in a manner or purpose for which the Product was not intended.

WARRANTORS' OBLIGATION UNDER THIS WARRANTY IS LIMITED TO REPAIR OR REPLACEMENT OF THE PRODUCT ONLY. THIS WARRANTY DOES NOT COVER PAYMENT OR PROVIDE FOR THE REIMBURSEMENT OF PAYMENT FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

It must be clear that the Warrantors are not insuring your products/premises or guaranteeing that there will not be damage to your person or property if you use this Product. The Warrantors shall not be liable under any circumstances for damage to your person or property or some other person or that person's property by reason of the sale or use of this Product, or its failure to operate in the manner in which it is designed. The Warrantor's liability, if any, shall be limited to the original cost of the Product only. Use of this Product is at your own risk. Procedures for obtaining performance for Warranty: In the event that the Product does not conform to this Warranty, the Product should be shipped or delivered freight prepaid to a Warrantor with evidence of original purchase. If in any way you are not comfortable with the product or its Limited Warranty, we encourage you to return it unused for a full refund.

DO NOT DISASSEMBLE THIS PRODUCT. It does not contain any user serviceable components.