

# TRACEABLE® LONG-STEM THERMOMETER INSTRUCTIONS

## SPECIFICATIONS:

Model:	4052	4352	4353	4354
Range:	-58 to 302°F	-58 to 302°F	-58 to 572°F	-58 to 572°F
	-50 to 150°C	-50 to 150°C	-50 to 300°C	-50 to 300°C
Accuracy:	±1°C	±0.2°C	±1°C	±0.5°C
Length Stem:	8"	8"	11.4"	11.4"
	Overall:	11"	14.4"	14.4"
Diameter: Stem:	1/8"	1/8"	1/8"	1/8"
	Top:	1.2"	1.2"	1.2"

- Display:** 3/8" LCD
- Resolution:** 0.1° above -20 and below 200  
1.0° below -20 and above 200
- Sampling Rate:** 10 seconds in Fahrenheit mode  
1 second in Celsius mode
- Features:** Stainless steel probe  
protective plastic sleeve

## OPERATION

1. To turn the thermometer on slide the ON/OFF switch to the ON position.
2. To measure in Fahrenheit select the "F" position of the F/C switch or "C" to measure in Celsius.
3. Remove the protective plastic sleeve of the thermometer probe and insert the probe into the material to be measured.
4. To turn the thermometer off slide the ON/OFF switch to the OFF position.  
To conserve battery life, always turn the unit off when not in use.

## ALL OPERATIONAL DIFFICULTIES

If this unit does not function properly for any reason, replace the battery with a new high-quality battery (see "Battery Replacement" section). Low battery power can occasionally cause any number of "apparent" operational difficulties. Replacing the battery with a new fresh battery will solve most difficulties.

## BATTERY REPLACEMENT

Erratic readings, a faint display, or no display, are all indicators that the battery must be replaced. Remove the battery cap, located at the top of the unit by turning it in the direction of the arrow (counterclockwise). Remove the exhausted battery and replace with a new 1.5 volt battery. Replace the battery cover. Do not overtighten the cap. Replacement battery Cat. No. 1039.

## WARRANTY, SERVICE, OR RECALIBRATION

For warranty, service, or recalibration, contact:

## TIP TEMPerature Products

340 W. Broad Street  
Burlington, NJ 08016

Tel: 1-800-847-8367 Fax: (609)  
239-1911

Web: [www.tiptemp.com](http://www.tiptemp.com)

Cat. No. 4052 | 4352 | 4353 | 4354

Traceable® Digital Long-Stem Thermometer Instructions

92-4052-10

Rev. 3 040809

Traceable® is a registered trademark of Control Company

© 2009 Control Company